



POLYMER BATHROOM/KITCHEN EXHAUST VENT

INSTALLATION GUIDE

ITEM #'S: BVDS4BK, BVDS4BR, BVDS4DB, BVDS4GR, BVDS4WH,
BVDS4WG, BVDS6BK, BVDS6BR, BVDS6DB, BVDS6GR, BVDS6WG
BVDS6WH



⚠️ WARNING!: Failure to comply with these instructions will void manufacturer warranty.

- 1) When installing on new construction, be sure the vent is facing in the correct direction by placing the molded arrow so it points toward the ridge line of the roof.
- 2) As typical with any roof ventilation, the front part of the molded flashing (downhill side) should rest over a layer of shingles beneath it.
- 3) **⚠️ DO NOT USE PNEUMATIC NAILERS/STAPLERS:** The molded flashing has seven (7) premolded nails holes that should be used to secure the flashing to the sheeting using a roofing hammer or similar. The use of pneumatic nail guns or staplers will damage the integrity of the flashing, may not allow for expansion and contraction potentially causing cracking. This may result in leaks and faulty roof installation. Using pneumatic nail guns/staplers or failing to use the premolded holes will VOID the Manufacturer Warranty.
- 4) As more layers are installed the roofing should begin to cut around the vent hood and over the flashing to eventually being covered by the roofing completely at the top.
- 5) **⚠️ DO NOT USE TAR OR PETROLEUM BASED CAULK OR ADHESIVE. DO NOT USE CAULK UNLESS NEEDED.**

FIGURE 1:

⚠️ DO NOT NAIL OR STAPLE THROUGH FLANGE EXCEPT WHERE PROVIDED!

This Side Up



The BVDS comes with seven (7) premolded holes as shown. These holes are for installation purposes. Failure to use them or the use of pneumatic nail may cause failure and VOIDS the manufacturer warranty.